

## STONE AGE

CONCRETE TABLE TENNIS

Limited 10 Year Warranty

**What This Warranty Covers:**

All concrete and steel parts against defects for material and workmanship for a period of 10 years.

### Stone Age Concrete Games, Inc. Installation Instructions — ADA Vantage Concrete Table Tennis Table



**Unload all items using proper equipment.**

**Required for offloading:**

Forklift or other lifting device such as backhoe or tractor with forks. Please follow manufacturers lift and distance weight ratings.

**Tools:**

- 1 1/8" socket
- Hex drivers
- Hand Truck (dolly)
- 4' level
- Electric screwdriver for shipping pallet
- Phillips bits for packaging
- Two 12' lifting straps
- Lifting hook or shackle

**Safety:**

All components are heavy and require care in placement until installation is complete. Use equipment and straps rated for lifting and inspected before use. Keep body parts clear of pinch points during placement. Runner to leg connections must be tightened before top halves are placed.

**Quality Note:**

Steel runner and net components must be TOUCHING concrete/threaded inserts to avoid stress fractures to concrete when tightening bolts. Use washers as shims if needed. Do not over tighten 3/8" net and table bolts.

**What This Warranty Covers:**  
All concrete and steel parts against defects for material and workmanship for a period of 10 years.

## **Stone Age Concrete Games, Inc. ADA Vantage Concrete Table Tennis Table**

### **Installation Instructions**

1. Bolt legs to the powder coated steel frame using 3/4" bolts and lock washers. Level frame by shimming under legs if needed.
2. Install floor L brackets using roto-hammer and supplied 1/2" anchor bolts.
3. Install the first top half over the legs (not on the cantilever side). The center line (net edge) of the table should line up 37 3/4" from the edge of the frame. It is extremely important — if the table is ever taken down and moved after installation, remove the cantilever top **FIRST**.
4. Line up and install 3/8" bolts with washers through the frame into the first table top. Leave bolts loose until both tops are aligned and all bolts are started.
5. Install net using provided flathead bolts.
6. Install second top on the cantilever side of the table.
7. Align and snug all frame table top bolts.

Installation notes: Lift tops with packaging in place using two 12' lifting straps positioned over the foam corner packaging. Use a locking hook or shackle for safety. Top weight is 800 lbs. Use rated lifting equipment.

